



Combined Application Guides

Reflex Steering Stabilizers, Davis TruTrac Bars, and Anti-Sway Bars

Reflex Steering Stabilizers Application Guide

Following are the applications for the Roadmaster Reflex Steering Stabilizers family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

Model	Sub-Assembly	Year	Comments	Item #	Notes	Drilling Time	Wt.
BEAVER							
MISC		89-94	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK6	No Bracket Only	1	
CHEVROLET/GMC							
P SERIES	P30/P32/P3500	81-99	REFLEX STEERING STABILIZER (UNIT NEEDED RSSP30) WITHOUT OEM DAMPER	RBK3	No Bracket Only	1	
P SERIES	P30/P32/P3500	98-06	REFLEX STEERING STABILIZER RSSCP30 (REPLACEMENT FOR OEM DAMPER) WITH RETURN TO CENTER FEATURE	RSSCP30	No Bracket Only	1	
P SERIES	P30/P32/P3500	81-99	REFLEX STEERING STABILIZER (RSDP30 UNIT NEEDED)	RBK3	No Bracket Only	1	
3500 CLASS C CUTAWAY	WITH DUAL CROSS MEMBERS	04-08	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)	RBK17	No Bracket Only	1	
1500/2500/3500 VAN	WITH DUAL CROSS MEMBERS	04-08	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)	RBK17	No Bracket Only	1	
1500/2500/3500 VAN		95-04	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)	RBK15	No Bracket Only	1	
3500	CLASS C CUTAWAY	95-04	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)	RBK15	No Bracket Only	1	
1500/2500/3500 VANS	STEERING BOX OUTSIDE FRAME	71-95	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)	RBK1	No Bracket Only	1	
P SERIES	P30/P32/P3500	98-06	REFLEX STEERING STABILIZER RSDP30 (REPLACEMENT DAMPER ONLY)	RSDP30	No Bracket Only	1	
1/2 TON PICKUP	2 WHEEL DRIVE	98-04	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)	RBK15	No Bracket Only	1	
KODIAK	C4500/C5500	03-08	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK5	No Bracket Only	1	
P72-P92		96-97	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK6	No Bracket Only	1	
G30	CLASS C CUTAWAY	71-95	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)	RBK1	No Bracket Only		
COUNTRY COACH							
INTRIGUE		94-98	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK10	No Bracket Only	1	
DODGE							
Pickup	2500 - 3500 2WD & 4WD	03-08	Replaces Factory Dampener (UNIT NEEDED RSSB)	RBK20	64 No Bracket Only	1.5	
M-300/M-500		73-81	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK8	No Bracket Only	1	
FORD							
E450	V-10	87-08	REFLEX STEERING STABILIZER (UNIT NUMBER NEEDED RSSC)	RBK11	No Bracket Only	1	
F53	V10	00-09	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK9	No Bracket Only	1	
E450	WITH OEM DAMPER V8	87-08	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)	RBK11	No Bracket Only	1	

Reflex Steering Stabilizers Application Guide

Following are the applications for the Roadmaster Reflex Steering Stabilizers family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Comments</u>	<u>Item #</u>	<u>Notes</u>	<u>Drilling</u>	<u>Time</u>	<u>Wt.</u>
E350	WITH OEM DAMPER V8	89-08	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)	RBK11	No Bracket Only		1	
E350	V-10	87-08	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)	RBK11	No Bracket Only		1	
E450	WITHOUT OEM DAMPER V-8	87-09	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)	RBK2	No Bracket Only		1	
E250	WITH OEM DAMPER V8	87-08	REFLEX STEERING STABILIZER (UNIT NUMBER NEEDED RSSC)	RBK11	No Bracket Only		1	
F250	4WD	99-03	REFLEX STEERING STABILIZER (UNIT NEEDED RSSB)	RBK16	No Bracket Only		1	
F350	4WD	99-03	REFLEX STEERING STABILIZER (UNIT NEEDED RSSB)	RBK16	No Bracket Only		1	
EXCURSION	4WD	00-05	REFLEX STEERING STABILIZER (UNIT NEEDED RSSB)	RBK16	No Bracket Only		1	
F53	V8	89-07	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK4	No Bracket Only		1	
E250	WITHOUT OEM DAMPER V-8	87-09	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)	RBK2	No Bracket Only		1	
E350	WITHOUT OEM DAMPER V-8	87-09	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)	RBK2	No Bracket Only		1	
<u>FREIGHTLINER</u>								
AIR SUSPENSION	SOLID FRONT AXLE	06-08	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK18	No Bracket Only		1	10
FL SERIES	FL50,FL60	91-02	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK8	No Bracket Only		1	
AIR SUSPENSION	SOLID FRONT AXLE	95-05	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK14	No Bracket Only		1	
<u>GILLIG</u>								
DIESEL MODELS		94-06	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK6	No Bracket Only		1	
GAS MODELS		86-94	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK6	No Bracket Only		1	
<u>JOHN DEERE</u>								
MOTORHOME CHASSIS		86-94	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK8	No Bracket Only		1	
<u>MAGNUM</u>								
SAFARI VELVET RIDE		98-07	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK10	No Bracket Only		1	
SAFARI WITH LEAF SPRINGS		94-07	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK6	No Bracket Only		1	
BEAVER COACHES		94-06	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK6	No Bracket Only		1	
<u>NEWELL</u>								
NON-IFS			REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK6	No Bracket Only		1	
<u>OSHKOSH</u>								
Z-LINE			REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK8	No Bracket Only		1	
M-LINE			REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK8	No Bracket Only		1	
K-LINE			REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK8	No Bracket Only		1	
TORSION SUSPENSION			REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK6	No Bracket Only		1	
<u>ROADMASTER</u>								
STRAIGHT AXLE LEAF SPRING		00-09	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK8	No Bracket Only		1	
AIR RIDE		00-09	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK6	No Bracket Only		1	

Reflex Steering Stabilizers Application Guide

Following are the applications for the Roadmaster Reflex Steering Stabilizers family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Comments</u>	<u>Item #</u>	<u>Notes</u>	<u>Drilling</u>	<u>Time</u>	<u>Wt.</u>
MONACO ALL	EXCEPT DANA SPICER FRONT AXLE	00-09	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK6	No Bracket Only		1	
SPARTAN								
EXP CHASSIS		00-04	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK6	No Bracket Only		1	
WC SERIES		99-06	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK7	No Bracket Only		1	
N-LINE		91-07	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK7	No Bracket Only		1	
MOUNTAIN MASTER NON-IFS		93-07	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK7	No Bracket Only		1	
EC200	P-LINE	93-07	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK6	No Bracket Only			
WORKHORSE								
W SERIES CHASSIS	W18,W16	06-09	REFLEX STEERING STABILIZER (UNIT NUMBER NEEDED RSSA)	RBK12	No Bracket Only		1	
R SERIES	NON-IFS	03-07	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK13	No Bracket Only		1	
P SERIES	P30/P32/P3500	00-05	REFLEX STEERING STABILIZER RSDP30 (REPLACEMENT DAMPER ONLY)	RSDP30	No Bracket Only		1	
P SERIES	P30/P32/P3500	00-05	REFLEX STEERING STABILIZER RSSCP30 (REPLACEMENT FOR OEM DAMPER)WITH RETURN TO CENTER FEATURE	RSSCP30	No Bracket Only		1	
P SERIES	WITHOUT OEM DAMPER	00-05	REFLEX STEERING STABILIZER UNIT NEEDED (RSSP30)	RBK3	No Bracket Only		1	
W SERIES CHASSIS	W20,W22,W24	00-09	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	RBK13	No Bracket Only		1	

Davis TruTrac Application Guide

Following are the applications for the Roadmaster Davis TruTrac family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Comments</u>	<u>Item #</u>	<u>Notes</u>	<u>Drilling</u>	<u>Time</u>	<u>Wt.</u>
CHEVROLET/GMC								
Kodiak	4500	03-09	Front Trac Rod	TRAC 45-5500	54	No	1.5	27
Kodiak	5500	03-09	Front Trac Rod	TRAC 45-5500	54	No	1.5	27
Kodiak	4500	03-09	Front Trac Rod	TRAC 45-5500	54	No	1.5	27
Kodiak	5500	03-09	Front Trac Rod	TRAC 45-5500	54	No	1.5	27
FORD								
F53	V8	88-98	Front Trac Bar	Trac F53	No		1	25
F53	V10	98-05	Front Trac Bar	Trac V-10B	No		1	31
WORKHORSE								
W Series Chassis	W16, W18, W20, W22, W24	00-09	Front Trac Bar	Trac W-22	No		1	28

Anti-Sway Bar Application Guide

Following are the applications for the Roadmaster Anti-Sway Bar family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Comments</u>	<u>Item #</u>	<u>Notes</u>	<u>Drilling</u>	<u>Time</u>	<u>Wt.</u>
CLASS A								
BEAVER								
Santiam	8 Airbar Rear Radiator	05-09	Front sway bar 1 5/8 diameter for 8 air bag chassis rear radiator. RR8R chassis.	1169-110	No	2.5	86	
Santiam	8 Airbar Rear Radiator	05-09	Rear sway bar 1 5/8 diameter for 8 air bag chassis center rear radiator. RR8R chassis.	1169-109	Yes	2.5	90	
CHEVROLET/GMC								
P Series	P30/P32/P3500	68-99	Stage 1 susp. Kit. 1 5/8 diam. Front bar w/ poly bushing kit for 1 3/4 stock rear bar. Coil spring IFS (not for widebody).	1109-116	No	1.5	51	
P Series	P30/P32/P3500	68-99	Poly bushing kit for front 1 1/4 stock bar.	4109-109	No	0.5		
P Series	P30/P32/P3500	68-99	Poly bushing kit for rear 1 3/4 stock bar.	4109-106	No	0.5	5	
FORD								
F53	Super Duty, V10 Engine	92-98	Front poly bushing kit for OEM bar. 1 5/8 OEM bar.	4139-127	3	No	0.5	3
F53	Triton F53 Chassis, V10 Engine	98-06	Rear poly bushing kit for OEM bar - some endlink parts may not be used. 1 1/2 OEM bar.	4139-125	No	1	3	
F53	Super Duty, V8 Engine	92-98	Front poly bushing kit for OEM bar. 1 5/8 OEM bar.	4139-127	3	No	0.5	3
F53	V8 and V-10 Engine	99-10	1 3/4 Front factory replacement bar.	1139-140	No	1	50	
F53	Triton F53 Chassis, V10 Engine	98-05	Auxiliary rear sway bar 1 1/2 diameter (used w/ stock sway bar) over 18,000 lbs. GVWR. Retains stock factory rear bar.	1139-142	26,52	Yes	2	90
F53	TRITON F53 CHASSIS, V10 E	88-10	1 1/2 AUX RR 2006 and on fits both GVWR 18,000 lbs over and under retains factory swaybar	1139-143	52	Yes	2	85
F53	Super Duty, V8 Engine	92-98	Rear poly bushing kit for OEM bar - some endlink parts may not be used. 1 1/2 OEM bar.	4139-125	3	No	1	3
FREIGHTLINER								
XC Chassis	Air Suspension Only	95-98	Rear sway bar 1 1/2 diameter (for chassis w/ long 3/4 diameter u-bolts) most up to '98.	1209-105	5,41	Yes	2.5	89
FRED		07-08	1 3/4" diameter factory replacement front swaybar.	1209-129	61	No	1.5	54
FRED		07-08	1 1/2" diameter auxiliary rear swaybar.	1209-130	61	Yes	2.5	89
XC Chassis	Air Suspension Only	99-03	Rear sway bar 1 1/2 diameter (for chassis w/ short 7/8 diameter u-bolts) most '99-'03.	1209-115	5,45	Yes	2.5	89
HOLIDAY RAMBLER								
Endeavor	8 Airbar Rear Radiator	02-04	Front sway bar 1 5/8 diameter for 8 air bag chassis center rear radiator. RR8R chassis.	1169-108	No	2.5	86	
RR 8 R Chassis	8 Airbar Rear Radiator	02-04	Front sway bar 1 5/8 diameter for 8 air bag chassis center rear radiator. RR8R chassis.	1169-108	No	2.5	86	
RR 8 R Chassis	8 Airbar Rear Radiator	02-09	Rear sway bar 1 5/8 diameter for 8 air bag chassis center rear radiator. RR8R chassis.	1169-109	Yes	2.5	90	
Ambassador	8 Airbar Rear Radiator	05-09	Rear sway bar 1 5/8 diameter for 8 air bag chassis center rear radiator. RR8R chassis.	1169-109	Yes	2.5	90	
Endeavor	8 Airbar Rear Radiator	02-09	Rear sway bar 1 5/8 diameter for 8 air bag chassis center rear radiator. RR8R chassis.	1169-109	Yes	2.5	90	
Ambassador, Endeavor, RR8R chassis	8 Airbar Rear Radiator	05-09	Front sway bar 1 5/8 diameter for 8 air bag chassis rear radiator. RR8R chassis.	1169-110	No	2.5	86	
JOHN DEERE								
John Deere		86-88	1-5/8 diameter front sway bar	1169-144	Yes	2.5	87	
MONACO								
LaPalma	Diesel Engine Only	05-10	Rear sway bar 1.5 diameter.	1259-108	Yes	3		

Anti-Sway Bar Application Guide

Following are the applications for the Roadmaster Anti-Sway Bar family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

Model	Sub-Assembly	Year	Comments	Item #	Notes	Drilling	Time	Wt.
RR 8 R Chasis, Diplomat, Knight	8 Airbar Rear Radiator	05-09	Front sway bar 1 5/8 diameter for 8 air bag chassis rear radiator.	1169-110		No	2.5	86
Diplomat	8 Airbar Rear Radiator	02-09	Rear sway bar 1 5/8 diameter for 8 air bag chassis center rear radiator.	1169-109		Yes	2.5	90
Knight	8 Airbar Rear Radiator	05-09	Rear sway bar 1 5/8 diameter for 8 air bag chassis center rear radiator.	1169-109		Yes	2.5	90
RR 8 R Chassis	8 Airbar Rear Radiator	02-09	Rear sway bar 1 5/8 diameter for 8 air bag chassis center rear radiator.	1169-109		Yes	2.5	90
RR 8 R Chassis	8 Airbar Rear Radiator	02-04	Front sway bar 1 5/8 diameter for 8 air bag chassis center rear radiator.	1169-108		No	2.5	86

SPARTAN

Verst Chassis		07-08	Rear sway bar 1 1/2 diameter No bar connecting air bags. Jacks located to rear of cross member.	1149-121	56	No	2	
MC 2000	Air Suspension Only	95-03	Rear sway bar 1 5/8 diameter.	1149-106	2, 58	No	2	81
Verst Chassis	Air Suspension Only	97-03	Rear sway bar 1 1/2 diameter (late chassis) No bar connecting air bags.	1149-118	35	No	2	
Verst Chassis	Air Suspension Only	95-03	Rear sway bar 1 5/8 diameter (early chassis) w/ solid bar connecting air bags.	1149-106	2, 58	No	2	81
Verst Chassis	Air Suspension Only	04-06	Rear sway bar 1 1/2 diameter (late chassis) No bar connecting air bags.	1149-119	36	Yes	2	
Verst Chassis	Air Suspension Only	97-03	Rear sway bar 1 1/2 diameter (late chassis) No bar connecting air bags.	1149-118	39	No	2	
MC 2000	Air Suspension Only	96-03	Front sway bar 1 5/8 diameter (Holiday Rambler).	1149-1055		Yes	2.5	63
MC 2000	Air Suspension Only	96-06	Front sway bar 1 5/8 diameter.	1149-125	37	Yes	2	74
Verst Chassis	Air Suspension Only	04-06	Rear sway bar 1 1/2 diameter (late chassis) No bar connecting air bags.	1149-119	36	Yes	2	

WORKHORSE

W Series Chassis	W16/W18	05-10	Front sway bar 1 5/8 diameter.	1259-115		Yes	2	87
W Series Chassis	W20, W22, W24	00-10	Supplemental brackets for use when Ride Rite air bags are present. Welded application	590054-00		No	2	10
W Series Chassis	W20, W22, W24	00-10	Front sway bar 1 5/8 diameter.	1259-105		Yes	2	87
P Series		00-05	Front sway bar stiffener; widetrack only.	1109-200		No	1	25
W Series Chassis	W20, W22, W24	00-10	Rear sway bar 1.5 diameter.	1259-108	47, 55	Yes	3	
W Series Chassis	W16/W18	05-10	Combination front sway bar 1 5/8 diameter and front Trac Bar.	1259-116		Yes	3.5	
W Series Chassis	W20, W22, W24 Chassis	00-10	Front sway bar 1 5/8 diameter. Front trac bar combination.	1259-106		Yes	3.5	
W Series Chassis	W16/W18	05-10	Rear sway bar 1 1/2 diameter.	1259-118	51	Yes	3	

CLASS C

CHEVROLET/GMC

2500/3500	Van & Cut-away	04-10	1 1/2 front factory replacement.	1109-149		No	1.5	85
2500/3500	Van & Cut-away	77-10	1 3/8" diameter rear bar	1109-150	68	No	1.5	43
C3500	Pickup Cab	88-98	Front sway bar 1 3/8 diameter 2WD only.	1109-137		No	1	32
Kodiak	4500, 5500	03-10	Front sway bar 1 5/8 diameter.	1109-158		No	2	52
G30	Cut-away	75-96	Rear sway bar 1 1/4 diameter.	1109-121		Yes	1.5	41
G30	Cut-away	75-96	Front sway bar 1 3/8 diameter.	1109-131		No	1	37
G4500	Van & Cut-away	08-10	1 3/8" diameter rear bar	1109-150	68	No	1.5	43
Kodiak	4500, 5500	03-10	1 5/8 diameter rear facing rear auxillary bar	1109-157	57, 59	No	2.5	55

Anti-Sway Bar Application Guide

Following are the applications for the Roadmaster Anti-Sway Bar family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Comments</u>	<u>Item #</u>	<u>Notes</u>	<u>Drilling</u>	<u>Time</u>	<u>Wt.</u>
G4500	Van & Cut-away	08-10	1 1/2 front factory replacement	1109-149		No	1.5	85
<u>DODGE</u>								
Sprinter	3500	07-09	Aux Rear Swaybar 1.5" diameter retains factory bar	1209-131		Yes	2.5	60
B350		75-03	Rear sway bar 1 3/8 diameter.	1129-111	15	Yes	1.5	48
B250		75-03	Rear sway bar 1 3/8 diameter.	1129-111	15	Yes	1.5	48
Sprinter	2500	02-07	Rear sway bar 1 1/8 diameter	1209-117	63	No	1	25
Sprinter	2500	08-09	Rear swaybar 1 1/8 diameter factory replacement.	1209-128		No	1	25
Sprinter	3500	08-09	1 3/8 diameter factory replacement	1209-120	63	No	1	40
Sprinter	3500	04-07	Rear sway bar 1 3/8 diameter	1209-118	63	No	1	27
<u>FORD</u>								
E450	Super Duty	97-10	Rear sway bar 1 1/2 diameter.	1139-147	27	Yes	1	47
E350	Class C	92-10	Front sway bar 1 3/8 diameter.	1139-115	22	No	2	42
E450	Super Duty	97-10	Front sway bar 1 3/8 diameter.	1139-115	22	No	2	42
E350	Class C	75-10	Rear sway bar 1 1/2 diameter.	1139-117	19	Yes	1.5	53
E250	Class C	92-10	Front sway bar 1 3/8 diameter.	1139-115	22	No	2	42
E350		75-91	Front sway bar 1 3/8 diameter.	1139-100	18	No	1.5	37
<u>FREIGHTLINER</u>								
Sprinter	3500	04-07	Rear sway bar 1 3/8 diameter	1209-118	63	No	1	27
Sprinter	2500	02-07	Rear sway bar 1 1/8 diameter	1209-117	63	No	1	25
<u>WORKHORSE</u>								
3500	Cut-away	07-10	1 3/8" diameter rear bar	1109-150	68	No	1.5	43
3500	Cut-away	07-10	1 1/2 front factory replacement.	1109-149		No	1.5	85
<u>EV TYPE 1</u>								
<u>CHEVROLET/GMC</u>								
G4500	Van & Cut-away	08-10	1 1/2" diameter Rear factory replacment. Not for use with Auto-Chains.	1109-173		No	1.5	
Kodiak	4500, 5500	03-10	1 5/8 diameter rear facing rear auxillary bar	1109-157	57, 59, 62	No	2.5	55
G4500	Van & Cut-away	08-10	1 3/8" diameter rear bar	1109-150	65, 68	No	1.5	43
C3500	Pickup Cab (except HD)	86-98	Front sway bar 1 3/8 diameter 2WD only.	1109-137		No	1	32
G4500	Van & Cut-away	08-10	1 1/2 front factory replacement	1109-149		No	1.5	85
2500/3500	Van & Cut-away	04-10	1 3/8" diameter rear bar	1109-150	68	No	1.5	43
Kodiak	4500, 5500	03-10	Front sway bar 1 5/8 diameter.	1109-158		No	2	52
2500/3500	Van & Cut-away	04-10	1 1/2 front factory replacement.	1109-149		No	1.5	85
<u>DODGE</u>								
4500-5500	Chassis Cab	08-10	Rear swaybar kit 1.5" diameter factory replacement.	1129-131		No	2	
<u>FORD</u>								
F350	Super Duty	08-10	1 3/8" diameter factory replacement front swaybar super duty 4WD pickup and cab chassis SRW and dually.	1139-174		No	1	45
F450		99-06	Cab chassis rear sway bar 1.5 diameter (to replace factory bar) Round axle tube	1139-160	31	No	1	37
F450		08-10	Front bar 1.5 diameter 2WD & 4WD cab chassis F450-550	1139-171		No	1	55

Anti-Sway Bar Application Guide

Following are the applications for the Roadmaster Anti-Sway Bar family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Comments</u>	<u>Item #</u>	<u>Notes</u>	<u>Drilling</u>	<u>Time</u>	<u>Wt.</u>
F550		08-10	Front bar 1.5 diameter 2WD & 4WD cab chassis F450-550	1139-171		No	1	55
F550	Cab Chassis	05-07	Front sway bar 1 3/8 diameter for coil spring only - 4WD only.	1139-157	30	No	1	48
F350		05-08	Front 1 3/8 diameter sway bar. 2WD ONLY. To replace factory bar	1139-156		No	1	48
F550		00-08	Rear sway bar 1.5 diameter (to replace factory bar) square axle tubes.	1139-161	32	No	1	38
F450	Super Duty Pickup Cab	86-98	Rear sway bar 1 1/2 diameter w/ factory sway bar.	1139-123	23	Yes	2	35
F350	Cab Chassis	99-08	Rear sway bar 1.5 diameter (to replace factory bar) round axle tubes. 2WD & 4WD	1139-160	31	No	1	37
F450		08-09	Rear sway bar 1.5 diameter (to replace factory bar) square axle tubes	1139-161	32	No	1	38
F650	Chassis Cab	09-10	Front swaybar 1.5" diameter for Standard & LP Chassis 8,000lb & 10,000lb axle.	1179-121		No	2.5	
F350	Cab Chassis	05-07	Front sway bar 1 3/8 diameter. For coil spring only - 4WD only.	1139-157	30	No	1	48
F350	Cab Chassis	04-07	Front sway bar 1 3/8 diameter for coil spring only - 4WD only	1139-157	30	No	1.5	48
F650	Chassis Cab	09-10	Rear sway bar 1 5/8 diameter (for trucks equipped w/ On Spot chains) Will work w/ air brakes. LIMITED GROUND CLEARANCE	1179-110	67	Yes	2	90
F450	Cab Chassis	04-07	Front sway bar 1 3/8 diameter for coil spring only - 4WD only	1139-157	30	No	1.5	48
F550	Cab Chassis	04-07	Front sway bar 1 3/8 diameter for coil spring only - 4WD only	1139-157	30	No	1.5	48

FREIGHTLINER

M2		03-08	Rear sway bar 1 1/2 diameter - (front mount) Airliner w/o chains.	1209-107	43	Yes	2.5	90
FL Series	FL50, FL60	91-02	Front sway bar 1 1/2 diameter - 8000 lbs. axle.	1209-100	38	No	2	51
FL Series	FL50, FL60	91-02	Rear sway bar 1 1/2 diameter - Hendrickson air suspension only.	1209-101	39	Yes	2.5	89
FL Series	FL50, FL60	91-02	Rear sway bar 1 1/2 diameter - Hendrickson air suspension w/ chains only.	1209-104	40	Yes	2.5	89
M2		03-08	Rear sway bar 1 1/2 diameter - Airliner suspension (rear mount w/ chains). 5x4 u-bolt pattern.	1209-106	42	Yes	2.5	90
FL Series	FL50, FL60	91-02	Rear sway bar 1 1/2 diameter - Airliner suspension (rear mount w/ chains). 5x4 u-bolt pattern.	1209-106	42	Yes	2.5	90
M2		03-08	Onspot chains already on. Rear sway bar 1 1/2 diameter. Airliner 5x4 u-bolt pattern (rear mount).	1209-106SP		Yes	2	90
FL70		91-02	Rear sway bar 1 1/2 diameter w/ 6x4 u-bolt pattern. With Airliner air suspension.	1209-113	44	Yes	2.5	94
M2		03-08	Front sway bar 1 1/2 diameter 8000lbs axle. Will not fit w/ Mercedes engine auxillary cooling package.	1209-116	46	No	2	50
FL Series	FL50, FL60	91-02	Rear sway bar 1 1/2 diameter - (front mount) Airliner w/o chains.	1209-107	43	Yes	2.5	90
M2		03-08	Rear sway bar 1 1/2 diameter w/ 6x4 u-bolt pattern. With Airliner air suspension.	1209-113	44	Yes	2.5	94
FL Series	FL50, FL60	91-02	Onspot chains already on. Rear sway bar 1 1/2 diameter. Airliner 5x4 u-bolt pattern (rear mount).	1209-106SP		Yes	2	90
Sterling		05-06	Front sway bar 1 1/2 diameter	1209-119		No	2	50
FL70		91-02	Rear sway bar 1 1/2 diameter - Hendrickson air only. With 6 x 4 u-bolt pattern.	1209-112		Yes	2.5	89

NAVISTAR/INTERNATIONAL

4700 LP Series		89-02	Rear sway bar 1 1/2 diameter w/ Navistar factory air ride only.	1179-101		Yes	2.5	86
4700 LP Series		89-02	Front sway bar 1 1/2 diameter.	1179-100		No	2	63
43/4400 Series	Won't fit LP	03-08	Front sway bar 1 1/2 diameter 8,000 lbs axle. Will Not fit LP chassis	1179-108		No	2	63
43/4400 Series	Won't fit LP	03-08	Front sway bar 1 1/2 diameter 10,000 lbs axle. Will Not Fit LP Chassis.	1179-118		Yes	2	63

Anti-Sway Bar Application Guide

Following are the applications for the Roadmaster Anti-Sway Bar family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Comments</u>	<u>Item #</u>	<u>Notes</u>	<u>Drilling</u>	<u>Time</u>	<u>Wt.</u>
32/43/4400 SERIES	Low Profile and Standard	09-10	Front swaybar 1.5" diameter for LP Chassis 8,000lb & 10,000lb axle.	1179-121		No	2.5	
32/43/4400 Series		03-10	Rear sway bar 1 5/8 diameter (for trucks equipped w/ On Spot chains) Will work w/ air brakes. LIMITED GROUND CLEARANCE.	1179-110	67	Yes	2	90

STERLING

4500-5500	Chassis Cab	08-10	Rear swaybar kit 1.5" diameter factory replacement	1129-131		No	2	
-----------	-------------	-------	--	----------	--	----	---	--

EV TYPE 3

CHEVROLET/GMC

W4500	Cab Chassis	08-09	Rear sway bar 1 1/2" diameter For Tilt Cab Chassis	1109-172		No	2	80
G30 Cut-away	Cut-away	75-96	Rear sway bar 1 1/4 diameter.	1109-121		Yes	1.5	41
G30	Cut-away	75-96	Front sway bar 1 3/8 diameter.	1109-131		No	1	37
VAN	2500 & 3500	97-10	Rear sway bar 1 diameter	1109-148		Yes	1.5	30
2500/3500	Van & Cut-away	97-10	1 3/8" diameter rear bar	1109-150	68	No	1.5	43
2500/3500	Van & Cut-away	04-10	1 1/2 front factory replacement.	1109-149		No	1.5	85

DODGE

B200	Cut-away	75-03	Rear sway bar 1 3/8 diameter for cut-aways. Not for Sprinter.	1129-111	15	Yes	1.5	48
B300	Cut-away	75-03	Rear sway bar 1 3/8 diameter for cut-aways. Not for Sprinter.	1129-111	15	Yes	1.5	48
4500-5500	Chassis Cab	08-10	1 5/8" diameter front factory replacment.	1129-134		No	1	40

FORD

E450	Super Duty	97-10	Front sway bar: 1 3/8 diameter.	1139-115	22	No	1.5	42
E450	Super Duty	97-10	Rear sway bar: 1 1/2 diameter.	1139-147	27	Yes	1	47
E350	Cut-away	75-10	Rear sway bar 1 1/2 diameter motorhomes cut-aways.	1139-117		Yes	1.5	53
E350	Cut-away	92-10	Front sway bar 1 3/8 diameter.	1139-115	22	No	1.5	42
E250	Cut-away	92-10	Front sway bar 1 3/8 diameter.	1139-115	22	No	1.5	42
E350	Cut-away	75-91	Front sway bar 1 3/8 diameter motorhomes cut-aways.	1139-100	18	No	1.5	37
E350	Cut-away	75-09	Rear sway bar 1 3/8 diameter (w/ automatic chains). Rear facing.	1139-108	20	Yes	1.5	44

STERLING

4500-5500	Chassis Cab	08-10	1 5/8" diameter front factory replacment.	1129-134		No	1	40
-----------	-------------	-------	---	----------	--	----	---	----

SUV

CHEVROLET/GMC

Tahoe - Yukon		00-08	Rear sway bar 1 1/8 diameter (w/ factory bar).	1109-168	48	No	1	36
Escalade		00-08	Rear sway bar 1 1/8 diameter (w/ factory bar).	1109-168	48	No	1	36
Yukon	2500 XL	00-08	Rear sway bar 1 1/4 diameter (leaf spring suspension).	1109-160	12	Yes	1	28
Suburban		92-99	Rear sway bar 1 1/8 diameter (w/o factory bar).	1109-144	11	No	1.5	34
Suburban		92-99	Rear sway bar 1 1/8 diameter (w/ factory bar).	1109-142	10	No	1.5	23
Yukon		95-99	Rear sway bar 1 1/8 diameter (w/o factory bar).	1109-144	11	No	1.5	34
Tahoe		95-99	Rear sway bar 1 1/8 diameter (w/o factory bar).	1109-144	11	No	1.5	34
Suburban	2500	00-08	Rear sway bar 1 1/4 diameter (leaf spring suspension).	1109-160	12	Yes	1	28
Tahoe - Yukon		95-99	Rear sway bar 1 1/8 diameter (w/ factory bar).	1109-142	10	No	1.5	23

Anti-Sway Bar Application Guide

Following are the applications for the Roadmaster Anti-Sway Bar family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Comments</u>	<u>Item #</u>	<u>Notes</u>	<u>Drilling</u>	<u>Time</u>	<u>Wt.</u>
Avalanche		00-08	Rear sway bar 1 1/8 diameter (w/ factory bar).	1109-168	48	No	1	36
SUBURBAN		00-08	Rear sway bar 1 1/8 diameter (w/ factory bar).	1109-168	48	No	1	36
DODGE								
Durango		04-08	1 Rear factory replacement bar.	1129-126		No	0.5	40
FORD								
Expedition		97-03	Rear sway bar 1 1/8 diameter	1139-150		No	1	23
Excursion		00-05	Rear sway bar 1.375 diameter	1139-154		Yes	1.5	45
Excursion		00-05	Front sway bar 1 1/2 diameter	1139-155	29	No	1.5	40
JEEP								
Rubicon		04-08	Rear swaybar 1 1/8" diameter factory replacment.	1129-132		No	1.5	30

VAN/PICK-UP

CHEVROLET/GMC

Silverado		00-08	4 extended endlinks for vehicles with 4 lift kit installed	590045-00		No	0.5	10
C/K 3500	Standard & HD	00-07	Rear sway bar 1 1/4 diameter (2WD, 4WD & dually)	1109-167	13	Yes	1.5	40
2500/3500	Van & Cut-away	04-10	1 3/8" diameter rear bar	1109-150	68	No	1.5	43
Van	3500	97-10	Rear sway bar 1 diameter.	1109-148		Yes	1.5	30
2500/3500	Van & Cut-away	04-10	1 1/2 front factory replacement.	1109-149		No	1.5	85
C/K 3500	Standard & HD	08-09	Rear sway bar 1 1/4 diameter SRW 4X4 and Dually.	1109-171	8	No	1.5	47
C/K 2500	Standard & HD	00-08	Front Sway bar 1 1/2" diameter 2WD, 4WD, and Duallys, 2500, 3500 Factory replacement.	1109-166		No	1	45
C/K 2500	Standard & HD	00-09	Rear sway bar 1 1/4 diameter (2WD & 4WD)	1109-167	13	Yes	1.5	40
Van	2500	97-10	Rear sway bar 1 diameter.	1109-148		Yes	1.5	30
C/K 1500	Standard & HD	00-08	Rear sway bar 1 1/4 diameter (2WD & 4WD)	1109-167	13	Yes	1.5	40
C/K 3500	Standard & HD	00-09	Front Sway bar 1 1/2" diameter 2WD, 4WD, and Duallys, 2500, 3500 Factory replacement.	1109-166		No	1	45

DODGE

1500	Pick-up Ram	09-10	Rear sway bar 1 1/8" diameter factory replacment. 4X4 Only	1129-135		No	1	25
Sprinter	3500	04-07	Rear sway bar 1 3/8 diameter	1209-118	63	No	1	27
3500	Pick-up Ram	07-09	4X4, Dually and single rear wheel, 1 3/8" diameter rear swaybar	1129-130		No	1.5	41
1500	Pick-up Ram	96-02	Poly bushing kit for front factory bar	590053-00		No	0.5	10
2500	Pick-up Ram	96-02	Poly bushing kit for front factory bar	590052-00		No	0.5	10
Sprinter	2500	02-07	Rear sway bar 1 1/8 diameter	1209-117	63	No	1	25
2500	Pick-up Ram	96-02	Rear sway bar 1 1/4 diameter 96-02 (4WD).	1129-122	17	No	1.5	31
2500	Pick-up Ram	03-08	Rear sway bar 1 1/4 diameter 03-on (4WD) will fit single and dually.	1129-120	16, 69	No	1.5	31
B300	(conversion van only) 1 ton	75-03	1 3/8 rear sway bar	1129-111	15	Yes	1.5	48
Sprinter	2500	08-09	Rear swaybar 1 1/8 diameter factory replacement.	1209-128		No	1	25
B200-300	Van	75-03	Rear sway bar 1 diameter.	1129-107	14	Yes	1.5	34
Sprinter	3500	08-09	1 3/8 diameter factory replacement	1209-120	63	No	1	40
3500	Pick-up Ram	96-02	Rear sway bar 1 1/4 diameter 96-02 (4WD).	1129-122	17	No	1.5	31
3500	Pick-up Ram Dually 2WD	07-08	Rear sway bar 1 3/8" for 2WD Dually pickup only.	1129-133		No	1.5	80

Anti-Sway Bar Application Guide

Following are the applications for the Roadmaster Anti-Sway Bar family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Comments</u>	<u>Item #</u>	<u>Notes</u>	<u>Drilling</u>	<u>Time</u>	<u>Wt.</u>
3500	Pick-up Ram	03-06	Rear sway bar 1 1/4 diameter 03-on (4WD) will fit single and dually.	1129-120	16, 69	No	1.5	31
FORD								
F350		04-07	Front sway bar 1 3/8 diameter, coil spring only, 4x4 only	1139-158		No	1	48
F350		04-07	Rear sway bar 1 1/2 diameter	1139-170		No	1.5	49
E250	VAN & PICK-UP	92-10	Front sway bar: 1 3/8 diameter.	1139-115	22	No	1.5	42
F250		04-07	Front sway bar 1 3/8 diameter, coil spring only, 4x4 only	1139-158		No	1	48
F250		99-03	Rear sway bar 1 3/8 diameter F250 & F350 w/ factory bar only -99-03. No Dually.	1139-153	28	No	1.5	34
F350		99-03	Front sway bar 1 1/2 diameter (4WD) 99-03.	1139-155	29	No	1	40
F350		99-03	Rear sway bar 1 3/8 diameter F250 & F350 w/ factory bar only -99-03. No Dually.	1139-153	28	No	1.5	34
F250		99-03	Front sway bar 1 1/2 diameter (4WD) 99-03.	1139-155	29	No	1	40
F350		99-07	Rear sway bar 1 1/2 diameter F250 & F350 (dually).	1139-165	33	No	1	29
F250		05-08	Super Duty Front 1 3/8 diameter sway bar. 2WD ONLY. To replace factory bar	1139-156		No	1	48
E350	Van	75-06	Rear sway bar 1 3/8 diameter.	1139-109	21	Yes	1.5	51
F250		99-07	Rear sway bar 1 1/2 diameter F250 & F350 (dually).	1139-165	33	No	1	29
F450		08-10	Front bar 1.5 diameter 2WD & 4WD cab chassis F450-550	1139-171		No	1	55
F450		08	Front and rear polyurethane bushings to replace factory rubber bushings	590055-00		No	1	5
F350		05-08	Super Duty Front 1 3/8 diameter sway bar. 2WD ONLY. To Replace factory bar	1139-156		No	1	48
F350	Super Duty	08-10	1 3/8" diameter factory replacement front swaybar super duty 4WD pickup and cab chassis SRW and dually.	1139-174		No	1	45
F450		08-08	Rear bar 1.5" diameter Fits 4WD SRW & Dually Pickups.	1139-175		No	1.5	35
F250	Super Duty	08-10	1 3/8" diameter factory replacement front swaybar super duty 2WD & 4WD pickup and cab chassis SRW and dually.	1139-174		No	1	45
F150		04-06	1 1/8 rear bar. 4X4 only	1139-152		No	1	48
F350		08-10	Rear Swaybar 1 3/8 diameter factory replacment 4X4 and 2WD Must replace Factory Bar.	1139-173	66	No	1.5	40
E350	VAN & PICK-UP	92-10	Front sway bar: 1 3/8 diameter.	1139-115	22	No	1.5	42
E350	Van	75-06	Rear sway bar 1 1/8 diameter for auto chains.	1139-134	24	Yes	1.5	35
F250		04-07	Rear sway bar 1 1/2 diameter	1139-170		No	1.5	49
FREIGHTLINER								
Sprinter	3500	08-09	Rear Swaybar 1 3/8" diameter factory replacement.	1209-120	63	No	1	40
Sprinter	2500	02-07	Rear sway bar 1 1/8 diameter	1209-117	63	No	1	25
Sprinter	3500	04-07	Rear sway bar 1 3/8 diameter	1209-118	63	No	1	27
Sprinter	2500	08-09	Rear swaybar 1 1/8 diameter factory replacement.	1209-128		No	1	25
NISSAN								
Titan		07-07	1 1/8 diameter rear sway bar	1189-101		Yes	1	30
TOYOTA								
Tundra		07-08	5.7 liter V8 4x4. 1 rear sway bar	1189-102		No	1	40

Application Guide Notes Key

1. Modification may be required.
2. Welding required.
3. 1992 to mid-1995 have IPD-style bars with rubber bushings. Mid-1995 on have IPD-style bars with urethane bushings.
4. 18,000 lbs. GVWR and under.
5. Will not fit Newmar motorhomes.
6. Not for Oshkosh X, V, M or T line chassis (check with manufacturer for your model using VIN#).
7. 1991 and older require factory retro fit conversion kit.
8. Will Work with air bags.
9. With autochains and with and without air brake.
10. Will fit 1992-99 models with 4WD. For vehicles with factory sway bar for Suburban and 4 door Tahoe/Yukon – not for 2 door models.
11. Will fit 1999 models. For vehicles without factory bar. For Suburban and 4-door Tahoe/Yukon. Not for 2 door models.
12. For 2000-on GMC Yukon XL and Chevy Suburban (leaf springs 2500/3500 series) not for “regular” Yukon or Tahoe (coil springs – 1500 series).
13. For 2000-on Chevy/GMC 2500, 2500HD and 3500 (fits both single and dual rear wheels) pickups. Both gas and Duramax diesels. Will work with airbags.
14. Fits 80-2003 ¾ ton and 1 ton vans.
15. For 1975-03 Motor home chassis can be used on heavily loaded 1 ton vans.
16. 2003-06 Dodge 4WD pickups 2500 and 3500 models, both single and dual rear wheels. For stock ride height vehicles. May not fit with 5th wheel hitch.
17. 1996-02 4WD 2500 and 3500 pickups. Not designed for 2WD.
18. For 1975-91 only. Not for E150.
19. Fits 1975-2006 Motor homes and emergency vehicles. Will still work on 2005 gas E-series van cutaways.
20. For E350 DRW (dual rear wheels/cutaway) chassis 1975-2003 with automatic chains. Nor for use on diesel or V-10 models.
21. For 1975-2003 Ford E350 vans without chains. Type 2 Ambulance or Class B Motor home.
22. 1992-2006 also fits E-Super Duty, sometimes called E450. This kit has offset endlinks for tie rod clearance. Does not fit E250 or E150.
23. For 1988-91 F53 motor home chassis. Not for 1992 or newer motor homes. Also F450 pickup cab/chassis. 1986-97 to replace factory sway bar if not factory bar, additional parts will be needed (see Ford Dealer).
24. For 1992 models and newer vans (Type 2 Ambulance/Class B Motor Homes) except Powerstroke diesels and V-10 models. The exhaust is in the way! Kit could be mounted if customer is willing to modify exhaust.
25. For V-8 chassis and V-10 chassis with GVWR of 18,000lbs or less. The 4th digit of the VIN is L or M. GVWR is found on chassis data plate/sticker. These axle U-bolts are spaced 5” wide by 5.25” front to rear (Dana 80 axle). Will work with a tag axle if the drive axle has leaf springs.
26. For 1998-on F53 with V-10 engine and GVWR greater than 18,000 lbs. The 4th digit of VIN is N. GVWR is found on chassis data plate/sticker. U-bolt spacing is 5” wide by 6.25” front to back (Dana S135 rear axle). Will work with a tag axle if the drive axle has leaf springs.
27. Will work of the new 6 liter diesel engine for E450 chassis 1997-on. Mounts to axle same as factory bar and will work with chains. Replaces 1139-137. This bar has vertical forged ends.
28. For 1999-2003 F250/350 pickup single rear wheels with factory sway bar (both 2WD and 4WD). Replaces factory bar. If no factory bar endlinks will be needed (#590230-00) need 1 per vehicle. Will not fit 2004 or any dual rear wheels. Bar mounts under differential, not over differential like stock sway bar.
29. Front sway bar kit for 2000-04 Ford F250-F350 trucks with straight axle (all 4WD models and F450 with front leaf springs, and F550 2WD models). Replaces factory sway bar. Must have factory sway bar. Will not fit 2005-on with coil spring front suspension. Updated to exclude 1999 models. Will fit 1999 model when factory bar is present (added 1/2” hardware for 99 model year)
30. Front sway bar kit for 2005-on Ford F450-F550 4WD trucks with coil spring axle. Replaces factory sway bar. Must have factory sway bar. Will only fit cabin chassis, not for pickups.
31. Rear sway bar kit replaces factory sway bar. For F350 commercial cab/chassis (only Dana 80 rear end with shock bracket welded to axle). Will not fit any pickup. On F450 confirm Dana 80 axle (round axle tubes). If axle tubes are square (Dana 120) use kit #1139-161.
32. Rear sway bar for 2000-08 F550 cab/chassis. Replaces factory bar. Also fits F450 with Dana 120 axle (square axle tubes).
33. Rear sway bar for 1999-2007 F250 & F350 2WD and 4WD pickups with dual rear wheels and factory sway bar. Designed to replace factory sway bar. Not for lifted trucks.
34. For chassis with true air brakes with air canister on the axle. Some chassis have air assist brakes or air over hydraulic brakes, these are not true air brakes.
35. Rear sway bar kit for Spartan Verst, air suspension. 1996-on 1.5” diameter. Will not fit Renegade made by Harney Coach. Leveling jacks are in the way.
36. For Spartan Verst air suspension. 2004-on.
37. Fits Mountain Master M11 Verst Chassis.
38. For FL series chassis with 8,000lbs front axle and 19.5” rims or 126” wheel height. Normally used on FL50 or FL60 series low profile trucks (most ambulance chassis). This will not work with the new Cat diesel engine introduced in 2000.
39. For FL50 & FL60 ambulance chassis with Hendrickson air ride rear suspension. Will not work with chains (use 1209-104).
40. For Freightliner FL50/FL60 chassis with automatic chains. Proven to fit with Onspot. Arms of bar face towards rear of truck for Hendrickson suspension only.
41. For chassis up to 1998 and some 1999 and newer with long ¾” diameter. U-bolts on rear axle. Have customer or shop measure u-bolt diameter. For chassis with short 7/8” diameter U-bolts (most of 1999-on) use kit #1209-115. If rear suspension does not have U-bolts, we do not have a kit.
42. For 2000-on FL50/FL60 Airliner chassis with Freightliner air suspension 10/12K-15K GVW. If truck has Hendrickson air rear suspension, use #1209-010 or #1209-104 with chains. Bar mounts towards rear of chassis. For use with autochains. Not for Class A motor homes.
43. For FL series Airliner with Freightliner air suspension. Bar mount towards front of chassis. Not for use with chains. If vehicle is equipped with chains, use #1209-106.
44. For Freightliner FL70 with Airliner rear suspension. Rear facing bar.
45. For most 1999-2003 Freightliner XC. This kit is for chassis with short 7/8” diameter bolts on rear axle. NOTE: sometime in 2003 Freightliner suspension changed to a style with No U- bolts. Have customer/shop measure U-bolt diameter. For chassis with ¾” diameter U-bolts (mostly up to 1998) use kit #1209-105. If rear suspension does not have U-bolts (2003-on) we do not have a kit.
46. Will not work on chassis with Mercedes Benz engines that have auxiliary cooling package, if standard cooling, it is okay.
47. Update of kit #1259-106 now fits all years for Rear W22 Workhorse chassis. Also fits W20 chassis.
48. Fits Chevy 1/2 ton SUV chassis, coil spring only.
49. Will not fit with auto chains
50. Only fits vehicles with gas tanks that are rear of the axle.
51. Currently does not work with Super Hitch
52. Check to insure there is enough factory u-bolt available to accommodate the factory nut, washer and our ½” plate. If there is not enough u-bolts, the 590050-00 u-bolt replacement kit is needed.
53. If superhitch is installed the 590051-00 bracket kit is needed
54. For use with Duramax diesel will not fit gas engine.
55. When air bags have been added you will need the 590054-00 adapter kit which requires welding.
56. For Spartan Mountain Master Verst air suspension chassis Tuthill 240AR with jacks located to the rear of the cross member.
57. Will work with Kelderman air ride, Will work with Link Ultra ride.
58. Chassis must have 3” square beam connecting the 2 airbags located underneath.
59. Rear Leaf Spring hanger brackets may be bolted or riveted on. When riveted, install time will increase. Manufacture codes can be found under the driver side visor: EV8 = Rivets ; EV9 = Bolts.
60. Will not work with air bags.
61. Must have factory swaybars.

- 62. When installing with Link UltraRide (2) B315 endlinks will be needed.
- 63. 2007 Model year vehicles manufactured in or after June may have 2008 Chassis. Please confirm before ordering.
- 64. Will work with other model years that have the inverted Y front steering system with factory dampener.
- 65. Will work with automatic tire chains.
- 66. When no factory bar is present, customer will need to purchase factory endlinks from Ford.
- 67. For Applications Without onspot chains use 1179-110 and 590060-00.
- 68. Chassis built before June of 2007 will require an additional axle mounting bracket kit part # 590061-00.
- 69. Will NOT fit with Goose Neck Hitch.